

# Step 3: Determine the relationship between the geometry variable, the requirements, and material properties

- We have a simply supported beam with a rectangular cross-section
- The worst case occurs when the concentrated load,  $P$ , is applied at the center